



**049103/049104/049105/049106/049108/049109/049112/049113/  
049114/049118/049120/049124/049125/049126/049127/049128/  
049130/049131/231310/231311/**

## **READ CAREFULLY BEFORE INSTALLING**

**CAUTION:** Piston to cylinder wall clearance and piston ring end gap must be checked before installation.  
Refer to OEM workshop manual or piston and/or piston ring manufacturer for correct clearances.

PERFORMANCE PRODUCTS FOR HARLEY-DAVIDSON®



**049103/049104/049105/049106/049108/049109/049112/049113/  
049114/049118/049120/049124/049125/049126/049127/049128/  
049130/049131/231310/231311/**

## **READ CAREFULLY BEFORE INSTALLING**

**CAUTION:** Piston to cylinder wall clearance and piston ring end gap must be checked before installation.  
Refer to OEM workshop manual or piston and/or piston ring manufacturer for correct clearances.

PERFORMANCE PRODUCTS FOR HARLEY-DAVIDSON®



**049103/049104/049105/049106/049108/049109/049112/049113/  
049114/049118/049120/049124/049125/049126/049127/049128/  
049130/049131/231310/231311/**

## **READ CAREFULLY BEFORE INSTALLING**

**CAUTION:** Piston to cylinder wall clearance and piston ring end gap must be checked before installation.  
Refer to OEM workshop manual or piston and/or piston ring manufacturer for correct clearances.

PERFORMANCE PRODUCTS FOR HARLEY-DAVIDSON®